

0504 Honda Accord Aerodeck

- 1) Loosen the exhaust and the heat shield of the chassis.
- 2) Place tow bar with points (A) on the screw drillings provided in the chassis and point (B) comes against the towing ring in the middle of the vehicle. Bring in by point (A) and (C) the bolts and tighten.
- 3) Transfix points (B) until the trunk and bring in the bolts and washers via the trunk. Tighten everything, replace the heat shield and bring in the bolts by point (D). Attach the exhaust.
- 4) Assemble (*) and tighten everything firmly.

| | |
|--------------------------|---------|
| 1 tow bar ref. 0504 | |
| 1 ball T43x1 | (*) |
| 4 bolts M12x35 | (*) |
| 6 bolts M10/1,25x30 | (A) |
| 2 bolts + nuts M10x30 | (B) |
| 1 bolt + nut M12x40 | (C) |
| 1 bolt M6x20 | (D) |
| 9 washers 40x12x4 | (A-B-C) |
| 1 security washer 6 mm | (D) |
| 8 security washers 10 mm | (A-B) |
| 5 security washers 12 mm | (*.-C) |